

bosch-ebike.com

BOSCH eBIKE ABS

Greater safety, more
stability



BOSCH
Invented for life

The Bosch eBike ABS in summary

A perfect combination for more control, safety and stability.



The ABS for the front wheel optimises the riding stability and control of the eBike if the front wheel threatens to lock because the brake is applied too forcefully.



Rear wheel lift control reduces the chance that the rear wheel will lift off from the ground, particularly if the brake is applied very forcefully on a non-slip surface.



- ▶ The ABS light lights up and the corresponding message appears directly on the display (Kiox/ Nyon from MY 2021). The Bosch eBike ABS is not yet working.
- ▶ As soon as you reach around 5 km/h, the control light goes out. During the ride, it is off. Now, the Bosch eBike ABS is ready for use.
- ▶ If the control light does not turn off or lights up during the ride, there is an error: in this case, the Bosch eBike ABS will not be active.

If the battery is empty or missing, the Bosch eBike ABS is not active, and the ABS control light will not light up. Normal braking will still be available.



You'll find detailed warnings in the operating instructions.
www.bosch-ebike.com/en/products/abs